

TENANTS, LICENCE HOLDERS & LOGISTICS SERVICES

DARWIN PORT COMMON USER AREA		DARWIN PORT <u>NON</u> COMMON USER WORK AREA	
DP permits required when engaged to conduct work within a common user area.		DP permits required when engaged to conduct work within a non common user area (tenanted or licence holder area)	
	Permit to Work Form	#	#
SPECIALISED PERMITS	Confined Space	√*	χ
	Hot Works ¹	√	√
	Hot Works in Confined Space ¹	√	√
	Excavation / Digging	√	√
	Penetration	√	√
	Electrical Work (inc accessing substations)	√*	√*
	Fire System Impairment	√*	√*
	Working at Heights	√	χ
	Crane Operations (exemptions apply) ²	√	√
	Diving Operations	√	√
	Environment Emission / Impact ³	√	√

NOTES	Legend
<p>1 Hot Work and Hot Work in Confined Space Asco and Baker Hughes are exempt from obtaining these permits at their non common user area.</p> <p>2 Crane Operations Required where the crane has not be given an exemption by Darwin Port</p> <p>3 Environmental Emission / Impact means : Abrasive blasting or Water blasting Spray painting or Pesticide spray (Not herbicide) Earth works / Importing fill, Major maintenance / refurbishment Storm water system alteration, Works near / in Pond D Bird sanctuary Equipment wash down (excluding a wash bay) Discharge of any liquid, water, waste water to the harbour as part of planned activity (all discharges are subject to permit conditions) Concrete / diamond saw cutting</p>	<p>√ DP Permit to work <u>is</u> required</p> <p>χ DP Permit to work <u>is not</u> required</p> <p># Permit to work form is required only when a 'Specialised permit is required'</p> <p>√* Permit to work form is required for Darwin Port Infrastructure, contact DP if work required</p>

